

Viper Guide

Installation:

- Plug viper into power
 - Allow 15-20 minutes for the viper to warm up and be ready for use
- The viper will be ready to use once the ready light on the machine turns a solid green

Operation:

- Once the Viper is warmed up and ready to go press the menu button to the far left until a “P” is displayed with a number.
 - The “P” represents the manual mode and controls the output of smoke the values P1 – P99 will be displayed. The higher the number the larger the output of smoke.
- When the desired smoke output is set press the arrow button to the far right of the display to start the smoke.
- To stop the smoke press the same arrow button
- The viper can also be controlled through a DMX controller
 - Plug in your DMX cable and connect it to the DMX controller
 - To set the address keep pressing the menu button until a three digit number appears. This is the address number and can be set to addresses 001 – 512.
- To properly turn off the viper again cycle through the menu button until “OFF” is displayed on the screen. Then press the arrow key. A dot will appear on the display representing that the machine has properly been shut down and can now be disconnected from the power.